


# Over Temperature sensor circuit

## CIRCUIT DESCRIPTION


This sensor detects the over temperature and sends the appropriate signals to the HWS control ECU.

## WIRING DIAGRAM



## INSPECTION PROCEDURE

## 1 Check voltage between terminals T1 and T0 of HWS control ECU connector.

**PREPARATION:**

- (a) Remove HWS control ECU with connectors still connected.
- (b) Turn motor switch ON.

**CHECK:**

Measure voltage between terminals T1 and T0 of HWS control ECU connector at each temperature.

**OK:****Voltage:**

at 25°C (77°F)	0.35 – 0.43 V
at 40°C (104°F)	0.20 – 0.24 V

**HINT:**


As the temperature increases, the voltage decreases.

OK

Proceed to next circuit inspection shown on problem symptoms table (See page [DI-464](#)).

NG

## 2 Check over temperature sensor.

**PREPARATION:**

- (a) Remove engine under cover.
- (b) Remove over temperature sensor.

**CHECK:**

Measure resistance between terminals 1 and 2 of over temperature sensor connector at each temperature.

**OK:****Resistance:**

at 25°C (77°F)	1.6 – 1.8 Ω
at 40°C (104°F)	0.8 – 1.0 Ω
at 50°C (122°F)	0.5 – 0.7 Ω

**HINT:**

As the temperature increases, the resistance decreases.

NG

Replace over temperature sensor.

OK

3	Check for open and short in harness and connector between HWS control ECU and over temperature sensor (See page <a href="#">IN-28</a> ).
---	--

NG

Repair or replace harness or connector.

OK

Check and replace HWS control ECU.