


## INSPECTION

### 1. INSPECT MOTOR SWITCH CONTINUITY

Switch position	Tester connection	Specified condition
LOCK	–	No continuity
ACC	2 – 3	Continuity
ON	2 – 3 – 4, 6 – 7	Continuity
START	1–2–4, 6–7–8	Continuity


If continuity is not as specified, replace the switch.



### 2. INSPECT KEY UNLOCK WARNING SWITCH CONTINUITY

Switch position	Tester connection	Specified condition
SW OFF (Key removed)	–	No continuity
SW ON (Key set)	1 – 2	Continuity


If continuity is not as specified, replace the switch.




### 3. Key Unlock Warning System:

#### INSPECT INTEGRATION RELAY OPERATION


- Connect the positive (+) lead from the battery to terminal A1.
- Connect the negative (–) lead from the battery to terminals A5, A6 and A10.
- Check the buzzer sounds.



- Disconnect the negative (–) lead from the battery to terminals A6.
- Check that the buzzer stops sounding.



- Connect the negative (–) lead from the battery to terminals A6.
  - Disconnect the negative (–) lead from the battery to terminals A5.
  - Check that the buzzer stops sounding.
- If operation is not as specified, replace the relay.

**Junction Block Side**

I06882

**4. INSPECT KEY UNLOCK WARNING SYSTEM (INSPECT INTEGRATION RELAY CIRCUIT: Junction Block Side)**

Remove the integration relay from the instrument panel junction block and inspect the connectors on the junction block side.

Tester connection	Condition	Specified condition
4 – Ground	Passenger's door courtesy switch OFF	No continuity
4 – Ground	Passenger's door courtesy switch ON	Continuity
5 – Ground	Key unlock warning switch OFF	No continuity
5 – Ground	Key unlock warning switch ON	Continuity
6 – Ground	Driver's door courtesy switch OFF	No continuity
6 – Ground	Driver's door courtesy switch ON	Continuity
10 – Ground	Constant	Continuity
1 – Ground	Constant	Battery voltage
2 – Ground	Constant	Battery voltage
7 – Ground	Motor switch LOCK or ACC	No voltage
7 – Ground	Motor switch ON	Battery voltage
11 – Ground	Motor switch LOCK	No voltage
11 – Ground	Motor switch ACC or ON	Battery voltage
12 – Ground	Light control switch OFF	No voltage
12 – Ground	Light control switch TAIL or HEAD	Battery voltage

If the circuit is as specified, try replacing the relay with a new one.

If the circuit is not as specified, inspect the circuits connected to other parts.