



DISPOSAL

1. FULLY EXTEND SHOCK ABSORBER ROD
2. DRILL HOLE TO DISCHARGE GAS FROM CYLINDER

Using a drill, make a hole between the lines, as shown.

CAUTION:

The gas discharging is harmless, but be careful of chips which may fly up when drilling.