

TROUBLESHOOTING

SA00T-05

PROBLEM SYMPTOMS TABLE

Use the table below to help you find the cause of the problem. The numbers indicate the priority of the likely cause of the problem. Check each part in order. If necessary, replace these parts.

Symptom	Suspect Area	See page
Bottoming	1. Vehicle (Overloaded) 2. Spring (Weak) 3. Shock absorber (Worn out)	– SA-25 SA-52 SA-28 SA-49
Sways/pitches	1. Tire (Worn or improperly inflated) 2. Stabilizer bar (Bent or broken) 3. Shock absorber (Worn out)	SA-3 SA-39 SA-28 SA-49
Front wheel shimmy	1. Tire (Worn or improperly inflated) 2. Wheel (Out of balance) 3. Shock absorber (Worn out) 4. Wheel alignment (Incorrect) 5. Ball joint (Worn) 6. Hub bearing (Worn) 7. Steering linkage (Loosen or worn) 8. Steering gear (Out of adjustment or broken)	SA-3 SA-3 SA-28 SA-5 SA-37 SA-11 – –
Abnormal tire wear	1. Tire (Worn or improperly inflated) 2. Wheel (Out of balance) 3. Suspension parts (Worn) 4. Shock absorber (Worn out)	SA-3 SA-3 – SA-28 SA-49